



B3000-SB JUMPER SETTING

A. Speaker Out or Line Out Selection

J1 & J2		
Speaker Out	1-2	(Default)
Line Out	2-3	

B. CPU Clock Mode Selection

J3	Mode2	Mode1	Mode0	Multiple	CPU
	0	0	0	4x	133MHz
	0	0	1	10x	333MHz
	0	1	0	9x	300MHz
	0	1	1	5x	166MHz
	1	0	0	Reserved	
	1	0	1	6x	200MHz
	1	1	0	7x	233MHz
	1	1	1	8x	266MHz

0 --- Close

1 --- Open

C. Flash EPROM Read/Write Selection

J4		
Programming Enable (12V)	1-2	
Normal Operation (5V)	2-3	(Default)

D. Super IO CLK input Selection

CLKSIO	J5	
24MHz	1-2	(Default)
14.318MHz	2-3	

E. CMOS CLEAR Selection

J6		
Normal Operation	1-2	(Default)
Clear CMOS	2-3	